

Automatic Airless Spray Guns

311053K

EN

Part No. 26C624

For use with spraying high-pressure protective coating materials.

Part No. 288048

For airless spraying of paints and coatings.

Part No. 288554

For sealant streaming applications.

5000 psi (35 MPa, 345 bar) Maximum Working Fluid Pressure

Mounting manifolds must be ordered separately. Refer to Parts section.




Important Safety Instructions

Read all warnings and instructions in this manual before using the equipment. Save these instructions.




Important Medical Information

Read the medical alert card provided with the gun. It contains injection injury treatment information for a doctor. Keep it with you when operating the equipment.



Model 288048



Model 26C624











II 2 G Ex h T6 Gb

Contents

Warnings	3	Troubleshooting	16
Installation	5	General Troubleshooting	16
Ventilate Spray Booth	5	Spray Pattern Troubleshooting	18
Configure Gun and Manifold	5	Service	19
Install Air Fittings	6	Disassembly	19
Ground System	6	Reassembly	21
Mount Gun	7	Parts	22
Setup	8	Model 26C624	22
Air Line and Accessory Recommendations	8	Model 288048	24
Fluid Line and Accessory Recommendations	8	Model 288554	25
Flush Spray Gun	10	GG0 Series Tip Selection Charts	28
Install Spray Tip	10	XHD RAC Switch Tip Selection Charts	29
Adjust Spray Pattern	11	Sealer Application Tip and	
Adjust a Streaming Tip	11	Air Cap Selection Charts	30
Operation	12	Shower Tip	30
Pressure Relief Procedure	12	Streaming Tips	30
Apply the Fluid	12	Single Orifice Fan Pattern Spray Tips	30
Daily Gun Care	13	Accessories	31
General System Maintenance	14	Dimensions	32
Daily Cleaning Procedure	14	Mounting Hole Layout	34
Cleaning RAC Tips/Clearing Clogs	14	Technical Data	35
Daily Flushing Procedure	15	Graco Standard Warranty	36

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual or on warning labels, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.

 <h2>WARNING</h2>	
 	EQUIPMENT MISUSE HAZARD Misuse can cause death or serious injury. <ul style="list-style-type: none"> Do not operate the unit when fatigued or under the influence of drugs or alcohol. Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See Technical Specifications in all equipment manuals. Use fluids and solvents that are compatible with equipment wetted parts. See Technical Specifications in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request Safety Data Sheets (SDSs) from distributor or retailer. Turn off all equipment and follow the Pressure Relief Procedure when equipment is not in use. Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only. Do not alter or modify equipment. Alterations or modifications may void agency approvals and create safety hazards. Make sure all equipment is rated and approved for the environment in which you are using it. Use equipment only for its intended purpose. Call your distributor for information. Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces. Do not kink or over bend hoses or use hoses to pull equipment. Keep children and animals away from work area. Comply with all applicable safety regulations.
    	SKIN INJECTION HAZARD High-pressure fluid from dispensing device, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. Get immediate surgical treatment. <ul style="list-style-type: none"> Do not point dispensing device at anyone or at any part of the body. Do not put your hand over the fluid outlet. Do not stop or deflect leaks with your hand, body, glove, or rag. Follow the Pressure Relief Procedure when you stop dispensing and before cleaning, checking, or servicing equipment. Tighten all fluid connections before operating the equipment. Check hoses and couplings daily. Replace worn or damaged parts immediately.



WARNING



FIRE AND EXPLOSION HAZARD

Flammable fumes, such as solvent and paint fumes, in **work area** can ignite or explode. Paint or solvent flowing through the equipment can cause static sparking. To help prevent fire and explosion:



- Use equipment only in well-ventilated area.
- Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static sparking).
- Ground all equipment in the work area. See **Grounding** instructions.
- Never spray or flush solvent at high pressure.
- Keep work area free of debris, including solvent, rags and gasoline.
- Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present.
- Use only grounded hoses.
- Hold gun firmly to side of grounded pail when triggering into pail. Do not use pail liners unless they are anti-static or conductive.
- **Stop operation immediately** if static sparking occurs or you feel a shock. Do not use equipment until you identify and correct the problem.
- Keep a working fire extinguisher in the work area.



TOXIC FLUID OR FUMES HAZARD

Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.

- Read Safety Data Sheets (SDSs) to know the specific hazards of the fluids you are using.
- Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.



BURN HAZARD

Equipment surfaces and fluid that is heated can become very hot during operation. To avoid severe burns:

- Do not touch hot fluid or equipment.



PERSONAL PROTECTIVE EQUIPMENT

Wear appropriate protective equipment when in the work area to help prevent serious injury, including eye injury, hearing loss, inhalation of toxic fumes, and burns. Protective equipment includes but is not limited to:

- Protective eyewear, and hearing protection.
- Respirators, protective clothing, and gloves as recommended by the fluid and solvent manufacturer.

Installation

Ventilate Spray Booth



NOTE: Check and follow all National, State, and Local codes regarding air exhaust velocity requirements.

Check and follow all local safety and fire codes.

Configure Gun and Manifold

(Order manifold separately. See **Accessories**, page 31.)

Manifolds 241161 and 241162


The gun is supplied with an internal fluid plug (4). See FIG. 1. To use the gun in a circulating system, remove the internal plug. In a non-circulating system, leave the plug in place to minimize flush time.


Circulating System

1. Apply anti-seize lubricant 222955 to the threads and mating faces of the manifold (102) and the elbows (107), supplied unassembled.
2. Install the elbows (107) in both fluid ports of the manifold (102).
3. Connect the fluid supply line to one elbow and the fluid return line to the other. The manifold fluid ports are reversible.

Non-circulating System:

1. Apply anti-seize lubricant 222955 to the threads and mating faces of manifold (102), plug (109), and elbow (107), supplied unassembled.
2. Install an elbow (107) in one fluid port of the manifold (102), and a plug (109) in the other port.
3. Install the internal plug (4) in the gun fluid port on the same side as the manifold plug.
4. Connect the fluid supply line to the manifold elbow (107). See FIG. 1.
5. Install the gun on the manifold, using the four screws (14). Start the threads of all four screws, and tighten the front two screws first, and then tighten the back two screws to 65 in-lb (7.3 N•m).

 Remove when used in circulating systems.

 Replace with an elbow (107) when used in circulating systems.




FIG. 1: Non-Circulating Setup (Cutaway View)

Install Air Fittings

1. Install 1/4 in. tube fitting into the cylinder (CYL) air port.
2. Install plugs into the atomization (ATOM) air port and the fan (FAN) air port.




FIG. 2: Air Fittings

Ground System

<p>The equipment must be grounded to reduce the risk of static sparking and electric shock. Electric or static sparking can cause fumes to ignite or explode. Improper grounding can cause electric shock. Grounding provides an escape wire for the electric current.</p>			

The following grounding instructions are minimum requirements for a system. Your system may include other equipment or objects that must be grounded. Check your local electrical code for detailed grounding instructions for your area and type of equipment. Your system must be connected to a true earth ground.

Ground Pump

Ground the pump by connecting a ground wire and clamp between the fluid supply and a true earth ground as instructed in your separate pump instruction manual.

Ground Air Compressors and Hydraulic Power Supplies

Ground them according to the manufacturer recommendations.

Ground Air, Fluid, and Hydraulic Hoses Connected to Pump

Use only electrically conductive hoses with a maximum of 100 ft (30.5 m) combined hose length to ensure grounding continuity. Check the electrical resistance of your air and fluid hoses at least once a week. If the total resistance to ground exceeds 25 megohms, replace the hose immediately.

NOTE: Use a meter that is capable of measuring resistance at this level.

Ground Spray Gun

Ground the spray gun by connecting it to a properly grounded fluid hose and pump.

Ground Fluid Supply Container

Ground the fluid supply container according to local code.

Ground Object Being Sprayed

Ground the object being sprayed according to local code.

Ground Solvent Pails

Ground all solvent pails that are used with flushing according to local code. Use only metal pails, which are conductive. Do not place the pail on a non-conductive surface, such as paper or cardboard, which interrupts the grounding continuity.

Mount Gun

Reciprocating Arm Rod Mount

Manifolds 241161 and 241162

To mount the gun on a reciprocating arm rod [0.5 in. (13 mm) diameter maximum]:

1. Insert the mounting bar (A) through the hole in the manifold as shown in FIG. 3.
NOTE: Use the 1/8 in. alignment pin (P) to assist in orienting the gun.
2. Secure the gun to the bar by tightening the mounting screw (B).
3. Ensure the tip of the gun is 8 to 10 in. (150 to 200 mm) from the surface of the object being sprayed.




FIG. 3: Reciprocating Arm Mount

Stationary Support Mount

All Manifolds

To mount the gun on a stationary support (refer to FIG. 4. and **Mounting Hole Layout**, page 34):

1. Attach the gun to the support with two M5 x 0.8 capscrews (C). The screws must be long enough to engage the threaded holes in the gun manifold to a depth of 1/4 in. (6 mm).
2. Ensure the tip of the gun is 8 to 10 in. (150 to 200 mm) from the surface of the object being sprayed.







FIG. 4: Stationary Support Mount

Setup





Air Line and Accessory Recommendations

1. Install an air pressure regulator on the gun cylinder air supply line. A minimum of 70 psi (0.49 MPa, 4.9 bar) air pressure must be supplied to the cylinder for proper operation. Air pressure opens the valve, a spring closes the valve. A three-way air valve, which exhausts cylinder air, is required.
2. Install a bleed-type air shutoff valve on the main air line. Install an additional bleed-type valve on each pump air supply line, downstream of the pump air regulator, to relieve air trapped between this valve and the pump after the air regulator is shut off.

				
<p>The bleed-type air shutoff valve is required in your system to relieve air trapped between this valve and the pump after the air regulator is closed. Trapped air can cause the pump to cycle unexpectedly, which could result in serious injury.</p>				

3. Install a bleed-type air shutoff valve on the gun air cylinder supply line, downstream from the air regulator, to shut off air to the gun cylinder. Connect the air supply line to the gun cylinder air inlet (C). See Fig. 4.
- NOTE:** The cylinder air inlet accepts 1/4 in. (6.3 mm) O.D. tubing.

Fluid Line and Accessory Recommendations

				
<ul style="list-style-type: none"> • A fluid drain valve(s) is required in your system to assist in relieving fluid pressure in the displacement pump, hose and gun; triggering the gun to relieve pressure may not be sufficient. • A fluid pressure regulator must be installed in the system if the pump's maximum working pressure exceeds the gun's maximum fluid working pressure (see the front cover). 				

1. Install a fluid filter and drain valve(s) close to the pump's fluid outlet.
 2. Install a fluid pressure regulator to control fluid pressure to the gun.
- NOTE:** Some applications require fine-tuned control of fluid pressure. You can control fluid pressure more accurately with a fluid pressure regulator than by regulating the air pressure to the pump.
3. Install a fluid shutoff valve to shut off the fluid supply to the gun.
 4. For paint spray applications, install an in-line fluid filter, part 210500 or 26C633, on the gun fluid inlet (F) to avoid clogging the spray tip with particles from the fluid. See Fig. 5 on page 9.
 5. Connect the electrically conductive fluid hose to the gun fluid inlet (F) or optional in-line filter.

Manifolds 288219 and 288220

6. *In a circulating system*, connect an electrically conductive fluid hose to the gun fluid outlet (G).


In a non-circulating system, remove the gun fluid outlet fitting (G) and plug the outlet port with the pipe plug (109) supplied.

KEY

C Cylinder Air Inlet: accepts 1/4 in. (6.3 mm) O.D. tubing

F Fluid Inlet: 1/4-18 nptf or #5 JIC (1/2-20 unf)

G Fluid Outlet (circulating gun only): 1/4-18 nptf or #5 JIC (1/2-20 unf)

**FIG. 5****Manifold 244930**

7. This manifold is equipped with passages for circulating water to maintain the temperature of the gun. Ports provided are:

- Side water inlet, 1/4 npt(f)
- Top water outlets, 1/8 npt(f)
- Side RTD sensor, 1/8 npt(f)

See **Accessories**, page 31, for available fittings and sensors.



KEY

L Water Outlet: 1/8 npt(f)

M Air Inlet (to open valve): 1/8 npt(f)

N Fluid Inlet: 3/8(f)

P Water Inlet: 1/4 npt(f)

**FIG. 6**

Flush Spray Gun

Before running any paint through the spray gun:


1. Flush the gun with a solvent that is compatible with the fluid to be sprayed, using the lowest possible fluid pressure and grounded metal container. Follow the **Daily Flushing Procedure** procedure, page 15.
2. Perform **Pressure Relief Procedure**; see page 12.

Install Spray Tip



GG0 Tip


1. Perform **Pressure Relief Procedure**; see page 12.
2. Install the spray tip (H) and the gasket (J) in the tip retainer nut (K). Screw the assembly firmly onto the gun. Tighten the assembly with a wrench.




NOTE: Gaskets are included with Streaming Tips 270XXX or Fan Tips 182XXX.

RAC Tip

1. Perform **Pressure Relief Procedure**; see page 12.
2. Snap gasket (9b) on fluid seal (9a). Use tool (A) to insert gasket and seal into housing (insert the seal-end in first). Tip the tool to remove it once the seal is in place.



3. Install the tip cylinder (9c) as shown. Turn 90 counterclockwise to the spray position (the arrow should face forward). Install the assembled RAC onto spray gun.



Adjust Spray Pattern



1. To adjust the spray pattern direction with fan tips, orient the slot in the tip horizontally for a horizontal pattern and vertically for a vertical pattern. See Fig. 7.

RAC Tip only: Loosen tip guard retaining nut. Align the guard horizontally to spray a horizontal pattern. Align the guard vertically to spray a vertical pattern. Tighten the nut.

2. Start the pump. Adjust the fluid pressure until the spray is completely atomized. Use the lowest pressure necessary to get the desired results. Higher pressure may not improve the spray pattern and will cause premature tip wear and pump wear.
3. The spray tip orifice and spray pattern angle determines the coverage and size of pattern. When more coverage is needed, follow the **Pressure**

Relief Procedure, page 12, and install a larger spray tip rather than increasing fluid pressure.




FIG. 7: Spray Pattern

Adjust a Streaming Tip

Select a tip that will supply a stream at the required flow rate at the lowest pressure.

Operation

Pressure Relief Procedure




Follow the Pressure Relief Procedure whenever you see this symbol.



This equipment stays pressurized until pressure is manually relieved. To help prevent serious injury from pressurized fluid, such as skin injection, and splashing fluid, follow the Pressure Relief Procedure when you stop spraying and before cleaning, checking, or servicing the equipment.

1. Shut off the power to the pump.
2. Turn off the air and fluid supply to the gun.
3. Close the bleed-type master air valve (required in the system).
4. Trigger the gun into a grounded metal waste container to relieve the fluid pressure.



TI8174a

FIG. 8: Pressure Relief

5. Open the pump drain valve (required in the system) to help relieve fluid pressure in the displacement pump. In addition, open the drain valve connected to the fluid pressure gauge (in a system with fluid regulation) to help relieve fluid pressure in the hose and gun. Triggering the gun to relieve pressure may not be sufficient. Have a container ready to catch the drainage.
6. Leave the drain valve(s) open until you are ready to spray again.
7. If you suspect that the spray tip or hose is completely clogged or that pressure has not been

fully relieved after following the steps above, very slowly loosen the hose end coupling and relieve pressure gradually, then loosen the coupling completely. Now clear the tip or hose obstruction.


Apply the Fluid

Adjust the system control device, if it is automatic, so the gun starts spraying just before meeting the workpiece and stops as soon as the workpiece has passed. Keep the gun a consistent distance, 8 to 10 in. (200 to 250 mm), from the surface of the object being sprayed.

To achieve best results when applying fluid:


- Keep gun perpendicular and 8 to 10 inches (200 to 250 mm) from object being sprayed.
- Use smooth, parallel strokes across surface to be sprayed with 50% overlap. See FIG. 9.

Incorrect



TI8098a

Correct



TI8099a

FIG. 9: Correct Spray Method

Daily Gun Care



NOTICE

Methylene chloride with formic or propionic acid is not recommended as a flushing or cleaning solvent with this gun as it will damage aluminum and nylon components.

NOTICE

Solvent left in gun air passages could result in a poor quality paint finish. Do not use any cleaning method which may allow solvent into the gun air passages.

Do not point the gun up while cleaning it.



TI8100a

Do not wipe the gun with a cloth soaked in solvent; ring out the excess.



TI4827a

Do not immerse the gun in solvent.



TI8101a

General System Maintenance

- Perform **Pressure Relief Procedure**, page 12.
- Clean the fluid and air line filters daily.
- Check for any fluid leakage from the gun and fluid hoses. Tighten fittings or replace equipment as needed.
- Flush the gun before changing colors and whenever you are done operating the gun.

Daily Cleaning Procedure


NOTE: This gun is not adjustable. To ensure proper shutoff, screw the piston cap (18) onto the housing (1) until it bottoms out.

NOTE: Clean the front of the tip frequently during the day to help reduce buildup.

1. Follow **Pressure Relief Procedure**, page 12.
2. Clean the outside of the gun with a soft cloth dampened with compatible solvent.
3. To avoid damaging the spray tip, clean it with a compatible solvent and soft brush.
4. If using an in-line filter, remove and clean it thoroughly in a compatible solvent.
5. Clean the system's fluid filter and air line filter.

Cleaning RAC Tips/Clearing Clogs

1. Follow **Pressure Relief Procedure**, page 12.
2. Clean the spray tip:
 - a. RAC tips: Rotate the tip 180 so the arrow on the tip cylinder (9c) faces backward. Trigger the gun into a grounded metal waste container or onto the ground to remove the clog. Rotate the tip 180 back to the spray position.



- b. Flat tips: Remove the tip and clean with a solvent-soaked brush.
3. If the RAC tip is still clogged:
 - a. Shut off the sprayer and disconnect the power source.
 - b. Open the fluid drain valve and follow the **Pressure Relief Procedure** on page 12.
 - c. Remove and clean the spray tip.

Daily Flushing Procedure




To avoid fire and explosion, always ground the entire system, including the gun and waste container. To avoid static sparking and injury from splashing, always flush at the lowest possible pressure and maintain metal to metal contact between the gun and flushing pail.

NOTE: Flush the pump and gun before the fluid can dry in it.

NOTE: If it is available, the flushing procedure provided in the pump or sprayer manual should be used instead of this procedure.

1. Follow **Pressure Relief Procedure**, page 12.

2. Remove the spray tip. Clean the parts.
3. Supply a compatible solvent to the gun fluid inlet.
4. Start the pump and operate it at its lowest pressure.
5. Trigger the gun into a grounded metal waste container until all the material is removed from the gun passages.



6. Follow **Pressure Relief Procedure**, page 12.
7. Disconnect the solvent supply.

Troubleshooting



NOTE: Check all possible remedies in the troubleshooting charts before disassembling the gun.

NOTE: Some improper patterns are caused by the improper balance between air and fluid. Refer to **Spray Pattern Troubleshooting**, page 18.

General Troubleshooting

Problem	Cause	Solution
Fluid leakage through venting holes.	Worn o-rings or packings on needle assembly (12).	Replace o-rings or needle assembly.
Air leakage through venting hole.	Worn o-ring (23).	Check and replace as needed.
Air leakage from back of gun.	Worn o-rings (22, 23).	Replace o-rings.
Fluid leakage from front of gun.	Fluid needle (12) is dirty, worn, or damaged	Clean or replace fluid needle.
	Dirty or worn seat (10, 41).	Clean or replace the seat (10, 41) and gasket (11). The gasket must be replaced whenever you remove the seat from the gun.
	Spray tip seal is leaking.	Tighten nut (7) or replace spray tip gasket (8).
	Seat (10, 41) is insufficiently tightened or gasket (11) is missing or worn from multiple uses.	Tighten seat (10, 41) and replace gasket (11). The gasket must be replaced whenever you remove the seat from the gun.

Problem	Cause	Solution
Fluid needle will not trigger	Loose or missing fluid needle stop (17) or setscrew (16).	Replace stop (17) or tighten setscrew (16).
	Broken fluid needle (12).	Replace fluid needle (12).
	Air leaking around piston (21).	Replace o-ring (22) or piston assembly (21).
	Swollen piston o-ring (22).	Replace o-ring (22). Do not immerse piston in solvent.
	Insufficient air pressure on the trigger.	Increase the air pressure or clean the air line.
	Spray tip (9) is plugged.	Clean the spray tip (9).
	Plug (4) is in the incorrect fluid port.	Move the plug to the fluid port consistent with manifold plumbing, unless you are using the gun in a circulating system. If you are, all fluid ports should be open, both inside the gun and on the manifold.
Fluid does not shut off.	Piston cap (18) not fully tightened.	Tighten piston cap until it bottoms out.
	Spring (19) not in place.	Check spring position.
	Swollen piston o-ring (22).	Replace o-ring. Do not immerse piston in solvent.

Spray Pattern Troubleshooting

Problem	Cause	Solution
Fluttering spray.	Insufficient fluid supply.	Adjust fluid regulator or fill fluid supply tank.
	Air in paint supply line.	Check, tighten siphon hose connections, bleed air from paint line.
Spitting spray.	Worn seat (10, 41) or needle (12) ball.	Inspect seat and needle for wear. Replace if necessary. The gasket (11) must be replaced whenever you remove the seat from the gun.
	Dirty spray tip (9).	Clean.
	Swollen piston o-ring (22).	Replace o-ring. Do not immerse piston in solvent.
Irregular pattern.	Fluid build-up or spray tip partially plugged.	Clean spray tip; see Daily Gun Care , page 13.
Air cap loosening (sealant gun only).	Air cap (18) not properly tightened.	Tighten. See Reassembly , page 21, step 13.
	Gasket (38) worn.	Replace gasket.

Service



NOTE: Follow the Service Notes in Figs. 8 and 9 when reassembling the gun.

NOTE: Gun repair kits are available. See page 18. Reference numbers marked with an asterisk (*) in the service procedures are included with the 288171 Air Seal Repair Kit. Reference numbers marked with a symbol (†) in the service procedures are included with the 288137 Fluid Repair Kit.

Disassembly

1. Follow **Pressure Relief Procedure**, page 12.
2. Unscrew the four screws (14) and remove the gun from the manifold.
3. Unscrew the tip retainer nut (7). Remove the spray tip (9) and gasket (8). See Figs. 8 and 9.
4. Remove the cap (18) from the piston housing (1). Remove the springs (20 and 19).
5. Using the supplied wrench (34), loosen the fluid needle setscrew (16). Remove the needle stop (17).
6. Remove the seat (10, 41).

NOTICE


Be sure to keep the needle straight when removing it from the gun. If the needle is bent it must be replaced.

7. Pull the needle assembly (12) straight out the front of the gun. Remove the o-rings (31) from the fluid needle (12).
8. Remove the gasket (11).

NOTICE

Install a new gasket (11) whenever you remove the seat (10, 41) from the gun. Failure to install a new gasket may result in fluid leaking into the air chamber.


9. Remove the piston. Using a pliers, pull the piston (21) out of the piston housing (1).
10. If necessary, unscrew the two screws (15) holding the fluid housing (2) to the piston housing (1). If worn, remove the gasket (13) from the bottom of the piston housing.



T18197a

Fig. 10

11. Remove the large o-ring (22) from the piston and the smaller o-ring (23) from the piston shaft. Remove the two o-rings (25, 26) from each of the piston stems. Check that the stems are solidly in place. If they are loose, replace the entire piston assembly (21).
12. Perform the following applicable step:
 - *Non-circulating Paint Guns:* Remove the fluid outlet port plug (4) and gasket (3) from the fluid housing (2). Remove the o-ring (5) and backup (6) from the plug.
 - *Circulating Paint Guns:* Remove the gasket (3) from the fluid housing (2).
 - *Sealant Gun:* Remove the gasket (3).
13. Clean all parts and replace any worn parts. When assembling, lubricate the threads with anti-seize lubricant.



TI8117a

SERVICE NOTES:

- △1 Seat gasket (11) must be replaced if seat (10) is removed or replaced to avoid fluid leakage
- △2 Lubricate threads with anti-seize lubricant
- △3 Lubricate with light-weight oil
- △4 Do not lubricate
- △5 Torque to 20-25 ft-lb (27-34 N•m)
- △6 Apply semi-permanent anaerobic sealant
- △7 Torque to 6.5-7.5 in-lb (0.73-0.85 N•m)
- △8 Tighten cap (18) until it bottoms out
- △9 Model 288554 only

FIG. 11

Reassembly

1. Perform the following applicable step:

- *Non-circulating Paint Guns:* Lubricate the backup (6) and o-ring (5) and install them on the fluid outlet port plug (4). Install the plug in the fluid outlet port of the fluid housing (2). See FIG. 11. Reinstall the gasket (3).
- *Circulating Paint Guns:* Reinstall the gasket (3) in the fluid housing (2).
- *Sealant Gun:* Reinstall gasket (3).

2. Install the o-rings (22*, 23*) on the piston (21). Install two o-rings (25*, 26*) on each of the piston stems. Lubricate all the o-rings, the piston, and the piston stems.
3. Install the fluid housing (2) on the piston housing (1) with the gasket in place.
4. Reinstall the two screws (15) to secure the piston housing to the fluid housing (2). Torque to 30 in-lb (3.4 N•m).
5. Insert the piston (21) into the piston housing (1).
6. Remove the protective paper from the sticky side of the gasket (13*) and adhere the gasket to the bottom of the piston housing (1), making sure the three holes in the gasket are properly aligned with the matching holes in the housing.

NOTICE

Install a new gasket (11) whenever you remove the seat (10, 41) from the gun. Failure to install a new gasket may result in fluid leaking into the air chamber.

7. Install the o-rings (31) on the fluid needle assembly (12). Lubricate with light weight oil.


NOTICE

Be sure to keep the needle straight when installing it in the piston housing. If the needle is bent it must be replaced.

8. Insert the needle assembly (12) into the front of the fluid housing (2). Push it straight back through the piston.
9. Install a new gasket (11) in the fluid housing (2).
10. Lubricate the threads of the seat (10, 41). Screw it into the fluid housing (2) and torque to 20-25 ft-lb (27-34 N•m).
11. Install the needle stop (17) on the needle. Coat the setscrew (16) with semi-permanent anaerobic sealant and install the screw into the needle stop. Torque to 6.5-7.5 in-lb (0.73-0.85 N•m). Pull on the needle to make sure it seats fully.
12. Install the springs (19, 20).
13. Lubricate the threads of the piston housing (1). Screw the cap (18) onto the housing until it bottoms out.
14. *Model 288554 only:* Hand tighten cap (18) until it engages gasket (38). Then tighten cap a half turn more to ensure cap will not loosen during operation.
15. Do not lubricate the gasket (8). Install the spray tip (9) and gasket (8) in the tip retainer nut (7). Screw the assembly firmly onto the gun. Tighten the assembly with a wrench, but do not exceed 5 ft-lb (6.8 N•m) for model 233670 gun.
16. Reinstall the gun on the manifold with the four screws (14). Torque to 65 in-lb (7.3 N•m).

Parts

Model 26C624




SERVICE NOTES:

- ① Seat gasket (11) must be replaced if seat (10) is removed or replaced to avoid fluid leakage
- ② Lubricate threads with anti-seize lubricant
- ③ Lubricate with light-weight oil
- ④ Do not lubricate
- ⑤ Torque to 20-25 ft-lb (27-34 N•m)
- ⑥ Apply semi-permanent anaerobic sealant
- ⑦ Torque to 6.5-7.5 in-lb (0.73-0.85 N•m)
- ⑧ Tighten cap (18) until it bottoms out
- ⑨ Used on non-circulating guns only

Parts List

Ref.	Part	Description	Qty.	Ref.	Part	Description	Qty.
1	-----	BODY	1	19✓	114138	SPRING, compression	1
2	-----	HOUSING, fluid	1	20✓	114139	SPRING, compression	1
3†★	288200	GASKET, fluid, acetal homopolymer, pack of 10	2	21	240895	PISTON, assy	1
4	192687	PLUG, fluid, internal, SST	1	22*	115066	PACKING, o-ring, fluoroelastomer	1
5†	114244	PACKING, o-ring, fluoroelastomer	1	23*	111450	PACKING, o-ring, fluoroelastomer	1
6†	114340	RING, back-up, PTFE	1	25*	112319	PACKING, o-ring, fluoroelastomer	2
7	XHD001	GUARD, RAC tip	1	26*	111504	PACKING, o-ring, fluoroelastomer	2
9	XHDxxx	TIP, RAC switch (see XHD RAC Switch Tip Selection Charts , page 29)	1	34	114141	WRENCH, hex (not shown)	1
9a‡	-----	SEAL, fluid	1	---	▲222385	MEDICAL alert card (not shown)	1
9b‡	-----	GASKET	1	▲ Replacement safety labels, tags, and cards are available at no cost.			
9c	-----	TIP, spray, XHD RAC	1	* Parts included in Air Seal Repair Kit 288171 (purchase separately). The kit includes some parts that are not used on this gun.			
10✓	288196	DIFFUSER, seat, 3/16 in. ball	1	† Parts included in Fluid Seal Repair Kit 239896 (purchase separately).			
11†	189970	GASKET, diffuser/valve	1	✓ Keep these spare parts on hand to reduce down time.			
12✓	24B916	NEEDLE, cartridge, assy.	1	★ Not assembled. Install when the gun is mounted to the manifold blocks. See page 27. An extra gasket (3) is included as a spare.			
13*	114134	GASKET, polyethylene, bottom	1				
14	15H317	SCREW, mounting manifold (M5)	4				
15	15H318	SCREW, SHCS	2				
16	114137	SCREW, set, 6-32, 1/8 in. long	1				
17	192452	STOP, needle, SST	1				
18	192453	CAP, piston	1				
				‡ Included in OneSeal™ Repair Kit XHD010 (5 each per package). Purchase separately.			

Model 288048




T18090a

△ SERVICE NOTES:

- △1 Seat gasket (11) must be replaced if seat (10) is removed or replaced to avoid fluid leakage
- △2 Lubricate threads with anti-seize lubricant
- △3 Lubricate with light-weight oil
- △4 Do not lubricate
- △5 Torque to 20-25 ft-lb (27-34 N•m)
- △6 Apply semi-permanent anaerobic sealant
- △7 Torque to 6.5-7.5 in-lb (0.73-0.85 N•m)
- △8 Tighten cap (18) until it bottoms out
- △9 Used on non-circulating guns only

Model 288554



TI9523a

SERVICE NOTES:

- △1 Seat gasket (11) must be replaced if seat (41) is removed or replaced to avoid fluid leakage
- △2 Lubricate threads with anti-seize lubricant
- △3 Lubricate with light-weight oil
- △4 Do not lubricate
- △5 Torque to 20-25 ft-lb (27-34 N•m)
- △6 Apply semi-permanent anaerobic sealant
- △7 Torque to 6.5-7.5 in-lb (0.73-0.85 N•m)
- △8 Tighten cap (18) until it bottoms out
- △9 Used on non-circulating guns only

Parts

Ref.	Part	Description	Qty.	Ref.	Part	Description	Qty.
1	-----	BODY	1	19✓		SPRING, compression	1
2	-----	HOUSING, fluid	1	❖ 114138			
3†★	288200	GASKET, fluid, acetal homopolymer, pack of 10	2	◆ 120696			
4❖	192687	PLUG, fluid, internal, SST	1	20✓	114139	SPRING, compression	1
5†❖	114244	PACKING, o-ring, fluoroelastomer	1	21	240895	PISTON, assy	1
6†❖	114340	RING, back-up, PTFE	1	22*	115066	PACKING, o-ring, fluoroelastomer	1
7		NUT, retainer	1	23*	111450	PACKING, o-ring, fluoroelastomer	1
	❖ 171602			25*	112319	PACKING, o-ring, fluoroelastomer	2
	◆ 198391			26*	111504	PACKING, o-ring, fluoroelastomer	2
8	166969	GASKET, non-metallic	1	34	114141	WRENCH, hex (not shown)	1
9✓❖	GG0xxx	TIP (see GG0 Series Tip Selection Charts , page 28)	1	37	15H702	INSERT, plastic	1
10✓❖	288196	DIFFUSER, seat, 3/16 in. ball	1	40◆	15K097	GASKET, piston cap	1
11†	189970	GASKET, diffuser/valve	1	41◆	233671	SEAT, airless	1
12✓		NEEDLE, cartridge, assy.	1	---	▲222385	MEDICAL alert card (not shown)	1
	❖ 24B916			▲ <i>Replacement safety labels, tags, and cards are available at no cost.</i>			
	◆ 253886			* <i>Parts included in Air Seal Repair Kit 288171 (purchase separately). The kit includes some parts that are not used on this gun.</i>			
13*	114134	GASKET, polyethylene, bottom	1	† <i>Parts included in Fluid Seal Repair Kit 239896 (purchase separately).</i>			
14	15H317	SCREW, mounting manifold (M5)	4	✓ <i>Keep these spare parts on hand to reduce down time.</i>			
15	15H318	SCREW, SHCS	2	❖ <i>Model 288048 only.</i>			
16	114137	SCREW, set, 6-32, 1/8 in. long	1	◆ <i>Model 288554 only.</i>			
17	192452	STOP, needle, SST	1	★ <i>Not assembled. Install when the gun is mounted to the manifold blocks. See page 27. An extra gasket (3) is included as a spare.</i>			
18	192453	CAP, piston	1				

Part No. 241161

North America Manifold (NPT fittings)

Part No. 241162

International Manifold (JIC fittings)

Ref.	Part No.	Description	Qty.
101	192441	MANIFOLD, air	1
102	192442	MANIFOLD, fluid	1
103	120388	FITTING, tube, air inlet; 1/4 in. OD tube x 1/8 npt(m)	1
105	114246	SCREW, set; 5/16;0.437 in. long	1
107			2
	114342❖	ELBOW, fluid, male; 1/4 nptf(mbe); SST	
	114247◆	ELBOW, fluid, male; #5 JIC x 1/4 - 18 npt	
109	101970	PLUG, pipe, SST; 1/4-18 ptf, supplied to plug fluid outlet port in non-circulating applications	3
110	120453	SCREW, M3 x 18	1

❖ Part No. 241161 only.

◆ Part No. 241162 only.

△ Apply anti-seize lubricant (222955) to threads and mating faces of manifold and any fittings and/or plugs used in fluid ports.




FIG. 12: North America and International Manifold

Part No. 244930

High Flow Ambient or Temperature Conditioned Manifold for streaming or spraying.

Ref.	Part No.	Description	Qty.
201	198325	MANIFOLD, aluminum	1
202	110208	PLUG, 1/8 npt, SST	3




FIG. 13: Part No. 244930

GG0 Series Tip Selection Charts

GG0 Series Spray Tips

Orifice Size in. (mm)	* Fluid Output oz/min (lpm) at 600 psi (4.1 MPa, 41 bar)	Maximum Pattern Width at 12 in. (300 mm)								
		2 to 2.5 (50)	4 to 4.5 (100)	6 to 6.5 (150)	8 to 8.5 (200)	10 to 10.5 (250)	12 to 13 (300)	14 to 15 (350)	16 to 17 (400)	18 to 19 (450)
0.007 (0.178)	.053 (0.20)	107		307						
0.009 (0.229)	.087 (0.33)	109	209	309						
0.011 (0.279)	0.13 (0.49)	111	211	311	411	511	611			
0.013 (0.330)	0.18 (0.69)		213	313	413	513	613	713		
0.015 (0.381)	0.24 (0.91)	115	215	315	415	515	615	715	815	
0.017 (0.432)	0.31 (1.17)	117	217	317	417	517	617	717	817	917
0.019 (0.483)	0.39 (1.47)		219	319	419	519	619	719	819	
0.021 (0.533)	0.47 (1.79)		221	321	421	521	621	721	821	921
0.023 (0.584)	0.57 (2.15)			323	423	523	623	723	823	923
0.025 (0.635)	0.67 (2.54)			325	425	525	625	725	825	925
0.027 (0.686)	0.78 (2.96)			327	427	527	627	727	827	927
0.029 (0.737)	0.90 (3.42)				429	529	629	729		
0.031 (0.787)	1.03 (3.90)			331	431	531	631	731		931
0.033 (0.838)	1.17 (4.42)				433	533	633	733		
0.035 (0.889)	1.31 (4.98)			335	435	535	635	735		
0.037 (0.940)	1.47 (5.56)							737		
0.039 (0.991)	1.63 (6.18)					539	639			
0.041 (1.041)	1.80 (6.83)					541			841	
0.043 (1.092)	1.99 (7.51)					543	643			
0.045 (1.143)	2.17 (8.23)					545				
0.047 (1.197)	2.37 (8.98)					547		749		
0.049 (1.245)	2.58 (9.76)					553				
0.053 (1.35)	3.02 (11.4)						655			
0.055 (1.40)	3.25 (12.3)									

XHD RAC Switch Tip Selection Charts

XHD RAC Switch Tips

		ORIFICE SIZE - INCHES																	
Fan Width	in.	(mm)	0.007	0.009	0.011	0.013	0.015	0.017	0.019	0.021	0.023	0.025	0.027	0.029	0.031	0.033	0.035	0.037	0.039
	2-4	(51-102)	107	109	111	113	115	117	119	121									139
	4-6	(102-152)		209	211	213	215	217	219	221		225	227	229	231		235		239
	6-8	(152-203)	307	309	311	313	315	317	319	321	323	325	327	329	331	333	335	337	339
	8-10	(203-254)		409	411	413	415	417	419	421	423	425	427	429	431	433	435	437	439
	10-12	(254-305)		509	511	513	515	517	519	521	523	525	527	529	531	533	535	537	539
	12-14	(305-356)		609	611	613	615	617	619	621	623	625	627	629	631	633	635	637	639
	14-16	(356-406)			711	713	715	717	719	721	723	725	727	729	731	733	735	737	739
	16-18	(406-457)				813	815	817	819	821	823	825	827	829	831	833	835	837	839
	18-20	(457-508)									923		927		931	933	935	937	939
Flow Rate (gpm)			0.05	0.09	0.12	0.18	0.24	0.31	0.38	0.47	0.57	0.67	0.74	0.90	1.03	1.17	1.31	1.47	1.63
Flow Rate (lpm)			0.20	0.33	0.49	0.69	0.91	1.17	1.47	1.79	2.15	2.54	2.96	3.42	3.90	4.42	4.98	5.56	6.18

		ORIFICE SIZE - INCHES																		
Fan Width	in.	(mm)	0.041	0.043	0.045	0.047	0.049	0.051	0.053	0.055	0.057	0.059	0.061	0.063	0.065	0.067	0.069	0.071	0.075	0.081
	2-4	(51-102)																		
	4-6	(102-152)																		
	6-8	(152-203)	341	343	345	347		351		355										
	8-10	(203-254)	441	443	445	447	449	451		455		459	461	463	465	467		471	475	481
	10-12	(254-305)	541	543	545	547	549	551	553	555	557		561		565	567		571	575	
	12-14	(305-356)	641	643	645	647	649	651		655	657	659	661	663	665	667	669	671	675	
	14-16	(356-406)	741	743		747	749	751	753	755			761			767		771		
	16-18	(406-457)	841	843		847		851		855			861	863		867				
	18-20	(457-508)																		
Flow Rate (gpm)			1.8	1.98	2.17	2.37	2.58	2.79	4.26	3.25	3.49	3.74	4.0	4.26	4.53	4.82	5.11	5.41	6.04	7.04
Flow Rate (lpm)			6.83	7.51	8.23	8.98	9.76	10.57	16.13	12.29	13.20	14.14	15.12	16.13	17.17	18.24	19.34	20.48	22.85	26.66

Sealer Application Tip and Air Cap Selection Charts

Shower Tip

Number of Orifices	Orifice Size <i>in. (mm)</i>	Part
6	0.021 (0.533)	C08224

Streaming Tips

Orifice Size <i>in. (mm)</i>	Part	Orifice Size <i>in. (mm)</i>	Part
0.025 (0.635)	270025	0.039 (0.991)	270037
0.027 (0.686)	270027	0.041 (1.041)	270039
0.029 (0.736)	270029	0.043 (1.092)	270041
0.031 (0.787)	270031	0.045 (1.143)	270043
0.035 (0.889)	270035	0.057 (1.448)	270059

Single Orifice Fan Pattern Spray Tips

Orifice Size <i>in. (mm)</i>	Fan Width at 12 in. (300 mm) <i>in. (mm)</i>	Part
0.021 (0.533)	8-10 (200-250)	182421
	10-12 (250-300)	182521
	12-14 (300-350)	182621
	14-16 (350-400)	182721
	16-18 (400-460)	182821
0.023 (0.527)	8-10 (200-250)	182423
	10-12 (250-300)	182523
	12-14 (300-350)	182623
	14-16 (350-400)	182723
	16-18 (400-460)	182823
0.025 (0.635)	8-10 (200-250)	182425
	10-12 (250-300)	182525
	12-14 (300-350)	182625
	14-16 (350-400)	182725
	16-18 (400-460)	182825
0.027 (0.686)	8-10(200-250)	182427
	12-14 (300-350)	182627

Orifice Size <i>in. (mm)</i>	Fan Width at 12 in. (300 mm) <i>in. (mm)</i>	Part
0.029 (0.736)	8-10 (200-250)	182429
	12-14 (300-350)	182629
	16-18 (400-460)	182726
0.031 (0.787)	8-10 (200-250)	182431
	12-14 (300-350)	182631
	16-18 (400-460)	182831
0.035 (0.889)	8-10 (200-250)	182435
	10-12(250-300)	182535
	12-14 (300-350)	182635
0.039 (0.991)	8-10 (200-250)	182439
	10-12(250-300)	182539
	12-14 (300-350)	182639
0.043 (1.041)	8-10 (200-250)	182443
	10-12(250-300)	182543
	12-14 (300-350)	182643
	18-20 (450-500)	182643
0.047 (1.194)	18-20 (450-500)	182947

Accessories

Gun Manifolds

Order separately; not included with gun.
(See **Parts**, page 26.)

Part No. 241161

North America Manifold

Part No. 241162

International Manifold

Part No. 244930

High Flow Ambient or Temperature Conditioned
Manifold for streaming or spraying.

Grounding Clamp and Wire 222011

High Pressure Ball Valves, Fluoroelastomer Seals

5000 psi (34 MPa, 345 bar) Maximum Working Pressure
Can be used as fluid drain valve.

Part	Description
210657	1/2 npt(m)
210658	3/8 npt(m)
210659	3/8 x 1/4 npt(m)

Bleed-type Master Air Valve

250 psi (1.7 MPa, 17 bar) Maximum Working Pressure
Relieves air trapped in the air line between the pump air
inlet and this valve when closed.

Part	Description
107141	3/4 npt(m x f) inlet and outlet
107142	1/2 npt(m x f) inlet and outlet

Gasket Filter

Gasket filter 288201, package of 10. Small filter can be
installed in the inlet gasket (3) for added filtration.

Tube Fittings for Air or Water

250 psi (1.7 MPa, 17 bar) Maximum Working Pressure
160° F (71° C) temperature rating

Part	Length
104172	1/8 npt(m) x 1/4 OD tube
597151	1/8 npt(m) x 1/4 OD tube, 90° elbow (swivel)

Filter Kit

Consists of just the filter element
Filter 60 mesh, qty. 25 - 238564
Filter 60 mesh, qty. 3 - 238563
Filter 100 mesh, qty. 25 - 238562
Filter 100 mesh, qty. 3 - 238561


Brush 101892

For cleaning the gun.

In-line Fluid Filter

6150 psi (42.4 MPa, 424 bar) Maximum Working
Pressure Fits onto the gun fluid connector. 1/4-18 npsm

Part	Description
210500	100 mesh. Includes the parts shown below. Consists of filter element 205264.
26C633	60 mesh. Consists of filter element 205265.



Needle/Diffuser Options

Needles must be used only with the specified seat to
guarantee proper seating and life.

- Standard viscosity/standard flow
 - Fluid Needle 24B916, 3/16 in. carbide ball
 - Seat 288196
- Acid catalyzed materials/very low viscosity materials
 - Fluid Needle 241468, 3/16 in. plastic ball
 - Seat 288196

Temperature Sensor and Cable

For temperature conditioned manifold

Part	Length
198457	RTD Sensor, 100 ohm, 1/8 npt(m) with 3 pin Picofast connector
198458	RTD cable, 6 ft. (1.83 m) Flex cable to St. Clair connector

XHD RAC Guard, SST XHD003

Dimensions

288048, 288554




FIG. 14

26C624




FIG. 15

Mounting Hole Layout




FIG. 16: Manifold Mounting Hole Layout

Technical Data

Spray Guns 288048 and 288554		
	US	Metric
Maximum working fluid pressure	5000 psi	36 MPa, 360 bar
Maximum working fluid pressure	100 psi	0.7 MPa, 7 bar
Minimum air cylinder actuation pressure at 4000 psi	70 psi	0.49 MPa, 4.9 bar
Minimum air cylinder actuation pressure at 5000 psi	75 psi	0.51 MPa, 5.1 bar
Maximum working fluid temperature		
Paint applications	120 °F	49 °C
Non-flammable sealant applications	140 °F	60 °C
Weight	1.17 lb	529 g
Wetted Parts	Stainless Steel, Carbide, Ultra High Molecular Weight Polyethylene, Acetal, PEEK, Chemically Resistant Fluoroelastomer, PTFE	

Spray Guns 26C624		
	US	Metric
Maximum working fluid pressure	5000 psi	36 MPa, 360 bar
Maximum working fluid pressure	100 psi	0.7 MPa, 7 bar
Minimum air cylinder actuation pressure at 4000 psi	70 psi	0.49 MPa, 4.9 bar
Minimum air cylinder actuation pressure at 5000 psi	75 psi	0.51 MPa, 5.1 bar
Maximum working fluid pressure		
Paint applications	160 °F	71 °C
Weight	1.24 lb	563 g
Wetted Parts	Stainless Steel, Carbide, Ultra High Molecular Weight Polyethylene, Acetal, PEEK, Chemically Resistant Fluoroelastomer, PTFE, Nylon	

Triggering Speed

These values apply to a new gun with a 6 ft (1.8 m), 1/4 in. (6.3 mm) OD cylinder air line and a 0.019 in. tip. These values will vary slightly with use and with variations in equipment.

Cylinder Air Pressure psi (kPa, bar)	Fluid Pressure psi (kPa, bar)	msec to fully open	msec to fully close
70 (0.49, 4.9)	600 (4.2, 42)	51	72
70 (0.49, 4.9)	1800 (12.4, 124)	56	73
70 (0.49, 4.9)	4000 (28, 280)	69	73

Sound Pressure Levels (dBA)

Sound pressure measured 3.28 ft (1 m) from equipment.

Input Fluid Pressures	
1500 psi (10.5 MPa, 105 bar)	4000 psi (28 MPa, 276 bar)
79.0 dB(A)	86.6 dB(A)

Sound Power Levels (dBA)

Sound power measured per ISO-9641-2.

Input Fluid Pressures	
1500 psi (10.5 MPa, 105 bar)	4000 psi (28 MPa, 276 bar)
75.7 dB(A)	86.3 dB(A)

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

For the latest information about Graco products, visit www.graco.com.

TO PLACE AN ORDER, contact your Graco distributor or call to identify the nearest distributor.

Phone: 612-623-6928 **or Toll Free:** 1-800-533-9655, **Fax:** 612-378-3590

*All written and visual data contained in this document reflects the latest product information available at the time of publication.
Graco reserves the right to make changes at any time without notice.*

Original instructions. This manual contains English. MM 311053

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA
Copyright 2018, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com
Revision K, June 2019